GasLab_® Pro Series Multi-Gas Sampling Data Logger



Operation Manual

Popular Models

100% CO2 - CM-1000-00-00-25-00 10% CO2 - CM-1000-00-00-25 25% O2 - CM-1000-00-00-52-00 25% O2 + 100% CO2 - CM-1000-00-52-25-00

> Up to 64 Customizable Sensor Configurations

CONTENTS

WELCOME	3
IMPORTANT SAFEGUARDS	3
PACKAGE CONTENTS	4
PRODUCT OVERVIEW	5
PRINCIPAL OF OPERATION	5
Instrument Overview	5
DEVICE DIAGRAMN	6
LCD DISPLAY	6
QUICK START GUIDE	7
Powering/Operation	7
DATA LOGGING	8
SETTINGS	9
DISPLAY SETTINGS	9
Date/Time (1/1)	9
Custom/Settings	9
USING THE FILTERS	10
CALIBRATION	
WHY IS CALIBRATION REQUIRED?	
FACTORY CALIBRATION	
ORDERING A Certificate of CALIBRATIONDURING PURCHASE	
USER CALIBRATION	
SPECIFICATIONS	13
TROUBLESHOOTING GUIDE	14
BATTERY GUIDE	
PRODUCT MAINTENANCE	15
CONTACT US	15

WELCOME

Thank you for selecting the **CM-1000 Gaslab® Pro, Multi-Gas Sampling Data Logger**. The CM-1000 series is designed to simultaneously measure multiple gas concentrations through a sampling method. This device features Li-ion rechargeable batteries which allows for 30+ hours of use.

The CM-1000 series data can be recorded to a micro SD card for retrieval and analysis. The full color LCD display details each sensor's reading as well as graphing the data on the screen. The CM-1000 was designed for applications like fire suppression testing, fumigation, scientific research, laboratory analysis and incubation.

Please take some time to read through this manual to become familiar with the Multi-Gas Sampling Data Logger. Also, please pay special attention to the important safeguards.

IMPORTANT SAFEGUARDS

To reduce the risk of fire, electrical shock and/or injury to persons, basic safety precautions should always be followed when using electrical appliances, including the following:

- READ ALL INSTRUCTIONS BEFORE USING THIS METER.
- Use only the included power supply to operate this meter. Inappropriate voltage supply could cause irreparable damage to this device.
- Do NOT use batteries other than the Li-ion 18650 3.7V rechargeable batteries
- Additional Li-ion 18650 3.7V rechargeable batteries (3) (can be purchased, here)
- Do not operate with an obstructed sample path. remove the luer caps prior to operation.
- Make sure that the tubes are securely attached to the meter **before** sampling a closed environment.
- Ensure the SD Card has the gold chips facing up and towards the user, for properuse.
- This meter is **not** designed for prolonged outdoor use.
- Do not expose this meter to water or any liquids utilize the included filters and water traps.
- Do not operate this meter if the enclosure is opened.
- Do not operate the device if it is malfunctioning.

SAVE THESE INSTRUCTIONS!

PACKAGE CONTENTS

Please verify that your package contains the following items before using the meter:

ALL UNITS:

- (1) CM-1000 Multi Gas Data Logger
- (3) Li-ion 18650 3.7V batteries (Installed)
- (1) Water Trap
- (1) Hydrophobic Filters
- (2) Particulate Matter filters
- (2) Barbed fittings for filters
- (1) Tubing Set 6'
- (1) 16 GB SD Card
- (1) SD Card Adapter
- (1) Manual
- (1) USB 1.5 cable
- (1) Carrying Case with keys



Figure 1: Basic kit - all units

OPTIONAL ACCESSORIES

If the meter is to operate in environments where humidity is very high (>95% RH), an *Extreme Moisture Trap* can be purchased separately. This filter will allow free flow of sampled air while keeping moisture out of the meter.

Note: Please contact our technical support staff for more details about these accessories, support@durridge.com

FEATURES

-Measures CO2, CO, O2, CH4, RH, AMB, DP and ALTI (Dependent upon device model)

- Options for CO2 measurement range: 1%, 5%, 10%, 20%, 30%, and 100%
- Large back-lit LCD Display, for easy reading of gas concentration, temperature, and humidity (Additional Li-ion batteries may be purchased individually, <u>here</u>.)
- On-board, built-in 2-graph data logging display
- Supplied with Li-ion 18650 3.7V rechargeable batteries, for longer lifespan
- -Audible and Visual Alarms
- -Data Logging to any size micro SD Card (16GB SD Card included)

PRODUCT OVERVIEW

The **GasLab® Pro Multi-Gas Sampling Data Logger** is designed to simultaneously measure multiple gas concentrations through a sampling method. Utilizing a micro pump, the device draws samples into the sensing chambers allowing each sensor to take a fast and accurate measurement of the sample.

Meters with logging capabilities are designed to record data over extended periods of time to a 16GB micro SD card. The SD card stores an indefinite amount of collected data points that can be retrieved later for analysis.

Real time data and graphing is available on all CM-1000's by rotating the device to a horizontal position.

The meters are ideal for applications such as, but not limited to monitoring of products with modified atmosphere packaging (MAP), bio incubation, industrial, and testing of fire suppression systems.

The devices built-in micro-pump ensures reliable operation and consistent readings based on user-selected time intervals.

PRINCIPAL OF OPERATION

The sensors inside this device use advanced sensing technologies to sense, as a function of transmitted light, or by fluorescence quenching by oxygen to identify the precise gas concentrations in a sampled setting.

Samples are pulled in through the tube inlet port and draw into the detection chamber by a micro-pump, then expelled through the tube outlet port. Ensure that the luer caps are both removed prior to operating the device. Failure to do so will provide incorrect readings and may result in damage to the device.

The measured gas concentration levels are shown on the full color LCD display section in real time and/or logged into micro SD memory card for later retrieval.

The device is factory calibrated immediately prior to shipping and will operate within the specified range and precision upon its arrival.

INSTRUMENT OVERVIEW



Button description:

MODE (1)	Enter the setting menu.
Up (ㅌ) / Down (ㅂ) / Left (ㅑ) / Right (ּɕ)	Change parameter values or select options.
Enter (J)	Execute a command
PUMP(ĸ)	Start the pump or data logger (Does not turn pump off, must wait for sample period)

LCD Display

The Full Color Liquid Crystal Display (LCD) shows the following features:

- CO2 concentration level in parts-per-million (ppm or %)
- 02/C0/CH4 concentration levels in percentage format (##. ##%)
- RH, AMB, DP. and ALTI
- Time, Battery Life (upper left)
- SD Card Logging Icon ON/OFF (upper right)
- Sampling Pump Active/Inactive (upper right)
- Percentage of batteries

1.1 Main LCD Display Screen

1.2 Built-In Data Log Screen

- A. Zone 1 Gas Concentration Display
- B. Zone 2 Gas Concentration or RH/T
- C. Zone 3 TEMP / BARO / DP
- A. Gas Concentration Levels (ppm or %)
- B. Y Axis PPM and Alarm Levels
 - C. X Axis Logger Time / Span





1.2 Built-In Data Log Screen

QUICK START GUIDE

- 1. Install filters and tubing included if necessary.
- 2. Turn the meter ON by switching the red power switch up on the left of the device.
- 3. Turn logging ON by pressing the PUMP button until the SD Card Icon displays a green inner square. When the sampling process is completed, you can hold the PUMP button until the SD Card Icon turns solid **white**.
- 4. When the SD Card is White, the pump will stop after 60 seconds of sampling. (user is able to set the sampling period to any time length).

POWERING THE METER

- 1. Power on: Switch the Red Power Button (A) Up, located on the left side of the device, to the UP position.
- 2. To turn off, Switch the Power Button (A) Down.
- 3. This device uses Li-ion rechargeable batteries, which can provide a 30+ hours charge.

Please note - when the device is charged with a USB cable it cannot be turned off

OPERATION

The red POWER switch on the left side of the device turns the unit ON/OFF. The PUMP button on the right side of the device's faceplate, enable/disable the pump/or logging functionality.

Make sure you read through these instructions thoroughly before using the device. This guide will help you become more familiar with the device's operation. Please read the *Important Safeguards* on page **3** before continuing.

IMPORTANT: Follow these instructions to ensure proper set up:

- **1.** After powered on, when pump is activated, the device will measure the data in real-time.
- 2. Before getting started you need to enter the settings screen, by holding the **Mode Button (I)**, to alter the settings of the device.
- **3.** Utilize the **UP** and **DOWN** arrow buttons to highlight the appropriate settings you wish to update. Once selected, the appropriate setting will be highlighted in **purple** and can be altered by using the **UP** and **DOWN** buttons. Once the appropriate settings have been selected, press and hold the **MODE** button to return to the main display screen.

Please note, you may wish to navigate to "auto power off" and "back-light time" in the settings screen to change the standard 30 second time / 60 minutes period to any custom length interval for noninterference

On the main display you will notice 3 zone squares:

- Zone 1 (top display sensor area) Zone 2 (bottom left - RH) and Zone 3 (bottom right - DP/AL/AMB)

1. To select a zone, use the **Left (F) / Right (G) arrow buttons** to select the parameter/ sensor to be adjusted, the zone will be highlighted in **red**.

2. Next, you can press the Right arrow button (G) to proceed to alter the settings use the Up (E)/Down

(H) arrow buttons to edit the parameter values or alarm levels for that zone.

DISPLAY ALL SENSOR READINGS

• Press/hold the **ENTER** button (J) to display all sensor readings. Press the **MODE** button (I) to return to the main screen. (See reference chart below, for factory default settings.

DATA STORAGE

This device features an included 16GB micro SD card; however, any size micro SD card can be utilized.

Once the GasLab® Pro Multi Gas Sampling Data Logger is turned on, you can gather data in real time. Data logs can be downloaded from the device's micro SD Card to an excel/csv. file and analyzed for further observation. The full color LCD display also features real-time data graphing by rotating the device to the horizontal position.

Before Logging

- 1. Verify the 16 GB SD Card is installed in the card slot correctly.
- (The gold tabs should point towards the front of the device/user see, 1.3 image)
- 2. Verify the batteries are fully charged before deployment. Charge/replace if necessary.

Measuring

- 1. Turn the CM-1000 series red power switch "ON".
- 2. Remove the luer caps on the top of the device from Inlet and Outlet ports.
- 3. Ensure that the PUMP is running, as accurate measurements cannot be made unless the PUMP key has been turned on.
- 4. Verify the CM-1000 displays GAS(S)/RH/TEMP on the main screen.

Recording Data

- 1. Place the CM-1000 Multi-Gas Sampling Data Logger in its desired location.
- 2. Connect the included tubing and filters as required to the top ports. (*see image on page10*).
- 3. To begin logging, press and hold the PUMP button. The inner square of the SD Card Icon in the top right-hand corner of the screen, will change color and the pump icon will begin to spin.
- 4. When the SD card icon inner square is **green**, the CM-1000 is recording data.
- 5. If the SD card icon inner square is **red**, this means that the SD card is damaged, missing, or full of data.
- 6. When the SD card icon is **green**, the pump will runcontinuously.
- 7. To stop logging, press and hold the **PUMP** button until the SD Card icon changes color.
- 8. When the SD card is **White/Red** the data is not being recorded.
- 9. Should the user wish to turn off the data logging feature, press and hold the **PUMP** key. The SD Card will appear **White**, and the pump will stop after *60 seconds* of sampling.

Managing Files

CM-1000 Log Files Reference

1-100224-301-C			EQUIPO 1	
Time	CO2(ppm) Eq 1	Temp(C)	RH(%)	DP(C)
05:10:10	600	32.76	70.25	26.63
05:10:12	600	32.76	70.26	26.63
05:10:14	500	32.73	69.79	26.49
05:10:16	500	32.72	69.5	26.41
05:10:18	500	32.76	69.26	26.39
05:10:20	600	32.74	69.22	26.36
05:10:22	500	32.77	69.14	26.37
05:10:24	500	32.73	69.17	26.34
05:10:26	600	32.71	69.22	26.33
05:10:28	600	32.74	69.11	26.34
05:10:30	600	32.73	69.09	26.32
05:10:32	600	32.75	69.16	26.36
05:10:34	600	32.73	69.19	26.35
05:10:36	600	32.75	69.14	26.35
05:10:38	600	32.73	69.34	26.38
05:10:40	500	32.73	69.33	26.38
05:10:42	500	32.74	69.3	26.37
05:10:44	600	32.74	69.31	26.38
05:10:46	600	32.75	69.38	26.41

- 1. The CM-1000 series stores "Log Files" on the removable SD card.
- 2. The excel/csv. columns are pre-labeled: Time / Gas Concentration / RH%/DP (C), Baro1 (ambient air)/ Baro2 (pressure inside the sensing chamber)
- 3. At the completion of your tests, remove the SD Card from the CM-1000.
- 4. Place the SD card into the included card adapter or simply place into your PC.
- 5. Open the Log files in Excel (.xlsx)
- 6. Success! You have downloaded/managed the data you recorded with your CM-1000 Series Multi-Gas Sampling Data Logger.

1.3 16GB gold chips, facing upright

SETTINGS

The settings screens will allow the user to access all the parameters, options, outputs, communications, and date/time settings available in the device.

The settings screen allows you to change the brightness and back-light color themes (4 available) on the device, as well as activate a back-light time specifically to save power. This setting will not affect the meter's functionality but will affect the battery life depending on how you set this parameter.

Additionally, you can alter the date/time, graph line settings, and flow rate levels.

ENTERING SETTINGS SCREEN

- 1. Press/hold the **MODE** button (I) to enter the setup menu.
- 2. Press the **MODE** button (I) to enter to the next page 2/2.
- 3. Press the UP / DOWN buttons to select options or change parameter values.
- 4. Then press the **ENTER** button (J) to confirm it. Press/hold Mode button (I) to return to the main screen.

ne mst page (1/2 - Date/Time		Default Settings
Date/Time	01/01/2017 ~2099 / 12/24-hour time	Pre-Set by Manufacturer
Continue alarm	Yes (The buzzer sounds continuously.) / No (The buzzer sounds once.)	NO
Screen auto rotate	Yes / No	YES
Backlight level	1~32 (The larger the number, the brighter the screen)	11
Background color	(There are a total of 4 background colors.)	Black
Backlight time	10~999 sec (Backlight display time)	30 seconds
Auto power off	1~999 min	60 minutes
Graph line 2	$CO_2/O_2/CO/CH_4$ (The second trend line shows the gas measurements.)	Graph line 2 set to O2
About	CO2Meter	N/A
The second page (2/2)		
Analog for Zone 1	0-10V/4~20mA (Zone 1 voltage or current output)	0-10V
Analog for 4-20mA	CO ₂ /O ₂ /CO/CH ₄ (Another analog output option)	CO2
Data log time	Data logging interval time	2 seconds
Flow rate level	1~5 (The larger the number, the greater the pump output)	5
Exhaust time	10~240 sec	60 seconds
Ventilate time	0~120 sec	0 seconds
Gas compensation	Yes / No (CO ₂ and O ₂)	NO
Sensor times info	Sensor recalibrated time and pump lifetime (The time is displayed in the countdown mode. If you need to calibrate the sensor or exceed the pump lifetime, the time will be displayed in red.) CO ₂ : 99999999 days O ₂ : 99999999 days CO: 99999999 days CH ₄ : 99999999 days Pump: 99999999 min	Default
Reset to factory	Yes / No (Recover the factory setting to cancel customize setting.)	Reset to factory
Sensor calibration	Please refer to the calibration section.	

The first page (1/2 - Date/Time)

USING THE FILTERS

To use this device properly, hoses/tubing must be attached to the inlet and outlet barb fittings securely. The device was shipped with extra luer fittings if they are needed. The micro pump inside the device will draw air from the inlet by vacuum effect, push it through the sensing chamber, and then exhaust the air outside the meter through the outlet port. Below are examples of the options for exhausting the sampled air; closed vs. open loop.

A closed loop system will remove a sample from a chamber or line, sample the gas, and return the sample back to the chamber or line.

An open loop system will remove a sample from a chamber or line, sample the gas, and eject the sample to ambient atmosphere.



CALIBRATION

All units are shipped factory calibrated. Factory calibration certificates are saved on the SD card included with your device.

Over time all sensors require recalibration to maintain their accuracy and repeatability. When it is time to recalibrate, end users have two choices: field/self-calibration OR returning the device to DURRIDGE for factory calibration.

WHY IS CALIBRATION REQUIRED?

Our Sampling Data Loggers use highly accurate and technologically advanced sensors. These rely on a variety of technologies to detect and measure the concentrations of your desired gas. Over time, these technologies can deteriorate to the point that they must be moved back to a standard point of reference.

To combat sensor drift, a well-planned and documented process is used to return the sensor as close to its intended operational state as possible.

1 POINT & 2 POINT CALIBRATION

There is a distinguishable difference between 1-point and 2-point calibration methods. One-point sensor calibration involves applying one reference gas, whereas 2-point calibration is done by provided two reference gases to the device for the sensor to stabilize or move back to a standard point of reference.

For 1-point calibration, the most accurate method is to expose the device to pure 100% nitrogen to accurately stabilize the sensor. 2-point calibration is carried out prior to shipping each CM-1000 device. This method is much more comprehensive and should only be followed if you are an advanced user. We recommend that the CM-1000 series be calibrated, annually.

(See step-by-step CM-1000 1 Point Calibration guide below page. 12)

As mentioned, 2-point calibration should only be performed if you are an advanced or experienced user who has performed this method multiples times prior.

We recommend contacting DURRIDGE for the 2-point calibration guidelines or reach out to us directly to calibrate the device at a nominal fee. You can reach us directly at, support@durridge.com or (978) 667 - 9556.

User Calibration - CM-1000 - 1 Point Calibration

The CM-1000 GasLab® Pro Multi Gas Sampling Data Logger Series is calibrated using 100% CO2 Gas

To enter 1-Point Calibration Mode, please follow the appropriate steps below:

- 1. Turn on CM-1000 and wait for display to initialize.
- 2. Press and hold Mode (I) until first menu page appears confirm the screen shows"1/2".
- 3. Press Mode (I) again, and the second menu page will appear "2/2".



- 4. Press the Down arrow button (H) to scroll until "Sensor Calibration" is highlighted in Red.
- **5.** Press the Enter button (J) and "Sensor Calibration" will now be highlighted in **Purple**.

6. Next, simultaneously press and hold both the UP (E) and Down (H) arrows at the same time to enter the specific "Sensor Calibration" page.

7. Press the Enter button (J) to highlight "Target Sensor" in Red.



8. Press the Down arrow button (H) to scroll through the available sensors, for 100% we will press the down button until "CO2" appears.

9. Press the Enter button(J) to select the desired target sensor.

- 10. Next press the Down arrow button (H) to highlight "Offset" in Red.
- 11. Connect your inlet port to a source of gas, such as 100% CO2 and wait for readings to stabilize.
- 12. Press the "Up" or "Down" arrow buttons to adjust the "Perform Reading" (ex. for CO2, read10000).
- 13. Press and Hold the Enter button (J) to return to the main displayscreen.
- 14. The CM-1000 series will now display approximately 99.99%.
- 15. Remove the 100% CO2 from the Inlet Port.
- 16. Congratulations, you have successfully calibrated the CM-1000!

SPECIFICATIONS

	CO ₂ : 1%, 5%, 10%, 20%, 30%, 100%
	CO: 0~1,000ppm
	O ₂ : 0~25%, < 2% FS / 0.1 mbar
Measurement Range &	CH₄: 5% 0-1%: ≤±0.1%
Accuracy	RH: 0~100%, ±3% @25°C (20~80%RH), others ±5%
	Temperature: 0~50°C,±1°C
	Barometer: 50~110kPa, ±0.4kPa
	CO ₂ : 1ppm, 10ppm, or 100ppm
	CO: 1ppm
	O ₂ : 0.01%
Display Resolution	CH ₄ : 0.01%
Display Resolution	RH: 0.01%
	Temperature: 0.01°C
	Barometer: 0.1mmHg
Alarm Volume	80db±5%@10cm
Operating Conditions	0~50°C(32~122°F), 0~95%RH, non-condensing
Storage Temp.	-20~60°C(-4~140°F)
RS485 CO2Meter Internal	RS485 ModBus BR19200
Power Supply	Rechargeable Battery: Li-ion 18650 3.7V
	AC Adapter: 5V±5% >1A, 100~240 VAC, 50/60 Hz
Storage Capacity	depend on SD card capacity (max.16G SD card)
Weight	480g (1.05 lbs.) - without batteries
Dimensions	225.8x99.6x55 mm (8.9 x 3.9 x 2.2 in.)

CM-1000 Pump Pneumatic Data

Max. Flow	500 ml/min
Max intermittent duty	380 to 400 mbar
Max. continuous pressure	150 mbar
Max. restart pressure	150 mbar
Max. vacuum	-360 to -400 mbar
Max. restart vacuum	-150 mbar

Electrical / General Data

Motor type	Standard DC
Rated power	3.5 to 5 V/90 mA
Protection class	IP00
Ambient Temperature	10 to 50°C
Media Temperature	10 to 50°C
Weight	17g (0.03lb)

Note: After power-on, it takes 20 minutes for the device to stabilize and measure the temperature and relative humidity, accurately.

EMC/RFI: Readings may be affected if the unit is operated within radio frequency electromagnetic field strength of approximately 3 volts per meter, however the performance of the instrument will not be permanently affected.

TROUBLESHOOTING GUIDE

Symptom / Issue	Possible Cause / Resolution
Pump does not ACTIVATE	If the user experiences issues with pump activation, press/hold the MODE key to enter into settings screen. Click ENTER to access 2/2 and modify "Flow Rate Level" to "5". If pump is still inactive, pump needs to be replaced – contact support@durridge.com
Device does not power ON	Make sure the power supply is connected properly and that there is power in the outlet the adapter is connected has the appropriate voltage. If using batteries, make sure they are not depleted.
Slow response	Check the air flow channels to make sure they are not obstructed.
Reading Error	Ensure that the Inlet/Outlet Luer Cap Fittings are removed to enable an accurate means of sampling.
Red SD Card Icon Appears	This indicates that the SD Card is either damaged, missing, or full of data. Replace SD Card.
LCD Display Turns Off During Measurements	If the user experiences LCD display turning off during calibration, measurements, or data logging – please reference the "settings" section to adjust backlight / auto power off from default settings.
LCD Screen Troubleshooting During Use	If the user experiences issues with the screen orientation, this setting can be changed by referencing the "settings" section and adjusting the "screen auto rotate" to " NO ".

Rechargeable Batteries Index



'Battery OK': Measurements are possible 'Battery Low': The battery needs to be recharged, measurements are still possible

Battery Exhausted': Measurements are not possible

Battery installation:

This device is supplied with Li-ion 18650 3.7V rechargeable batteries (3x), which are pre-installed upon device shipment.

Battery charging:

During battery charging, the temperature of the device will rise by $5^{\circ}C \sim 10^{\circ}C$. At this time, the measurements of temperature and humidity will be affected by temperature rise. This could cause an effect on the accuracy of temperature when charging. Please use a fan to blow toward the Temperature & Humidity Sensor (B) directly, in order to gain a compensated balance of temperature and humidity between that of the temperature sensor and surrounding area. (5V/1A USB adapter charger).

Safety and Product Care

To ensure correct and safe device use, please read the User Manual before using the device. Please handle the device lightly, do not subject the device to impact/shock.

- 1. Do not submerse the device in water or allow liquid to be sampled into the device. This will cause electric shock, fire or malfunction which may result in damage.
- 2. Do not keep the device in a hot/humid environment. Keep the device away from heat source or water.
- 3. Please use a standard USB power supply (such as PC's USB port, universal AC adapter with USB port).
- 4. Improper power supply can cause serious damage to the device or result in injury or death to the user.

Product Maintenance

- 1. The maximum capacity of the SD card is 16G. (This is five years' worth of space)
- **2.** During battery charging, the temperature of the device rises. The temperature and humidity sensors are affected. Currently, measurements are only for reference. After batteries are fully charged and the device cools down, measurements are reliable.
- 3. Repair Do not attempt to repair the device or modify the circuitry by yourself. Please contact Durridge if the device needs servicing.
- 4. Caution The CO sensor must be replaced every 3 years.
- 5. Cleaning Disconnect the power before cleaning. Use a damp cloth, do not use a liquid cleaning agent, such as benzene, thinner or aerosols.
- **6. Maintenance** Recommended that the user conducts a comprehensive test and calibration every year to ensure normal operation of the device.

CONTACT US

We are here to help!

For information or technical support, please contact us.

[™] support@durridge.com

(978) 667-9556

🔛 <u>www.durridge.com</u>

Address: Durridge Company Inc. 900 Technology Park Drive Billerica, MA 01821 USA

